




Installation Instructions for 9K Vity Cylindrical Locks

For factory prepared doors only



1. Install the latch so that the bevel on the latch bolt faces the strike.
 2. Adjust the outside rose so that the chassis is centered in the door. Install the chassis from the outside of the door.
 3. Install the inside liner, rose, lever and strike.
- For field door preparation and detailed installation instructions, see the following steps.

1 Position template




Figure 1

1. Fold the template and place in position on the high edge of the door bevel.
2. Mark the drill points.

Note: Suggested height from floor to centerline of the lock is 40 1/16". If steel frames are used, the latch centerline must be in line with the center of the strike preparation.

2 Bore two holes and install latch




Figure 2

1. Bore a 2 1/8" diameter hole from both sides of the door, to the center of the door.
2. Drill a 1" diameter hole from the edge of the door that intersects the 2 1/8" hole.
3. Mortise the door edge for the latch face.
4. Install the latch and check the door swing. Latch tabs should project into the 2 1/8" diameter hole. See figure 3 in step 3.

3 Install boring jig and drill two 5/16 inch diameter holes




Figure 3

1. Install the boring jig (KD303) onto the door and engage with latch tabs. Make sure the front edge of the jig is parallel with the door edge.
2. Drill two 5/16" diameter holes halfway into the door.
3. Turn the boring jig over and repeat steps one and two from the opposite side of the door.

Note: Replace the boring jig after ten door preparations.

4 Remove inside lever and trim




Figure 4

For inside levers with button or blank face:

1. Insert the spanner wrench tip into the lever keeper hole and depress the keeper.
2. Slide the lever off.
3. Using the spanner wrench handle, gently pry the rose from the liner.
4. Using the spanner wrench, unthread the rose liner and remove.

5 Adjust lockset to door thickness




Figure 5

- Retract the rose locking pin and rotate the outside rose liner in or out until the distance from the rose edge to the retractor center-line equals one-half the door thickness.

Note 1: For 1 3/4" doors, install the liner until it contacts the chassis screw heads, next rotate counter clockwise (less than 1/2 turn) until the rose locking pin engages.

Note 2: Make sure the locking pin locks into the rose liner.

Note 3: Locksets will fit doors 1 3/4" to 2 1/4" thick. (Spacer available for 1 3/8" doors.)

For keyed inside levers:

1. Remove the core and throw member (if not already removed). See *Interchangeable core service instructions* on the reverse side.
 2. Insert a screwdriver into the figure-eight core hole and into the keeper.
 3. Using edge of screwdriver, depress the keeper and slide the keyed lever off the sleeve.
- Caution:** You will not be able to remove the lever if the screwdriver blade is inserted too far past the keeper.
4. Using the spanner wrench handle, gently pry the rose from the liner (see figure 4).
 5. Using the spanner wrench, unthread the rose liner and remove.

6 Engage retractor in latch




Figure 7

- With the latch in place, install the chassis from the outside. Make sure the latch tabs engage the chassis frame and the latch tailpiece engages the retractor.

7 Install thru-bolts, liner, rose and lever




Figure 9

1. Install thru-bolt screws in top and bottom through bolt holes.
2. Thread the liner onto the chassis hub.
3. Insert the spanner wrench into the liner notch as shown in figure 9 and tighten the liner onto the door.
4. Slide the rose over the sleeve, then press the rose onto the liner. The rose should fit closely to the door surface.
5. With the lever pointing toward the hinges, push the lever on firmly until seated.

9 Install core




Figure 11

1. Insert the proper throw member into the core. Six pin cores require the number "6" throw member; seven pin cores require the number "7" throw member.
2. Insert the control key into the core and turn the key 15° clockwise.
3. Insert the core and throw member into the lever with the control key.
4. Rotate the key 15° counterclockwise and remove the key.

Figure 12

Interchangeable core service instructions

Periodic lubrication of the interchangeable core maintains the 9K series lockset in good working condition and prolongs its useful life. Use only one lubricant to periodically lubricate a core.

Do not mix lubricants. The following are acceptable lubricants:

- Powdered graphite • LPS®

To lubricate the core with powdered graphite:

1. Insert the control key into the core and rotate 15° clockwise.
2. Remove the core and throw member by pulling on the key.
3. Insert dry powdered graphite through the key opening face.
4. Holding the core in an inverted position, insert and withdraw a key several times to allow the graphite to sift into pin holes.
5. Insert the core and throw member into the lever with the control key.

6. Rotate the control key 15° counterclockwise and remove the key.

Caution: Since the control key is a high-security key, make sure to keep it protected.

8 Install strike plate




Figure 10

1. In alignment with the center of the latch bolt, mortise the door jamb to fit the strike box and strike plate.

Caution: (The deadlocking plunger of the latch bolt must not enter the strike plate. The plunger deadlocks the latch bolt and prevents forcing the latch when the door is closed.) Excessive gap may reduce security and/or cause malfunction of the latchbolt assembly. A maximum door gap of 1/8" is recommended.

2. Insert the strike box and secure the strike with screws provided.

Door reinforcement instructions

If fabricated hollow metal doors are used, determine whether the doors are properly reinforced to support the lock. If door reinforcement is not adequate, consult the door manufacturer for information on proper reinforcement.

Patents:

Products covered by one or more of the following patents:

U. S. Patents:

D290085, 4843852, 4262507,
4318558, 4428212, 4496178,
4428570, 4437695, 4779808,
5116170


Canadian Patents:

1229358, 1184774, 1194057

Other patents pending.

NOTES:

1. Allow plus tolerance for clearance per ANSI A115.2.
2. Lock and latch case support by door manufacturer.
3. Plaster guard by door manufacturer.
4. Prepare for #8-32 screw.
5. For 73K and 93K only! (63K and 83K "C" style trim will not cover these holes.)
6. For 63K and 73K only, 1" latch face available.



FRAME PREPARATION

2-3/4" BACKSET DOOR PREPARATION

Description:

DOOR and FRAME PREPARATION for
63K, 73K, 83K & 93K CYLINDRICAL LOCKS

BEST LOCK CORPORATION

Note:

Small ANSI Strike (STK), 2-3/4" Backset, 1-3/4" Door

Rev. Date:
8/93


Tem-
plate:

K08


R
E
V.
D

8K/9K STRIKES & BOXES


8KS2 Strike




8KS1 Box



8KS3 ANSI Strike



30HS4 Box










Notes:


1. Prepare for #8-32 machine screw or for # 8 wood screw. (Combination screw supplied.)
2. Prepare for #12-24 machine screw or for #12 wood screw. (Combination screw supplied.)
3. Allow plus tolerance for clearance per ANSI A115.2.

9K VARSITY SERIES—FUNCTION DESCRIPTIONS

Single keyed functions











Function & Diag. (ANSI No.)	Diagram	Description			
		Latch operated by	Outside lever locked by	unlocked by	Inside lever locked by unlocked by
AB F81		<ul style="list-style-type: none"> Rotating the inside lever, <u>OR</u> Rotating the outside lever—only when the inside push button is out. 	<ul style="list-style-type: none"> Pushing the inside button, <u>OR</u> Pushing and turning the inside button. Turning the button keeps the outside lever locked until the button is turned back. 	<ul style="list-style-type: none"> Turning the key in the outside lever, <u>OR</u> Rotating the inside lever, <u>OR</u> Closing the door—only when the button is not turned. 	Cannot be locked Always unlocked
D F86		<ul style="list-style-type: none"> Turning the key in the outside lever, <u>OR</u> Rotating the inside lever. 	Always fixed	Cannot be unlocked	Cannot be locked Always unlocked
E F92		<ul style="list-style-type: none"> Rotating the inside lever, <u>OR</u> Rotating the outside lever—only when the inside push button is out. Turning the key in the outside lever. 	<ul style="list-style-type: none"> Pushing the inside button, <u>OR</u> Pushing and turning the inside button. Turning the slotted button keeps the outside lever locked until the button is turned back. 	<ul style="list-style-type: none"> Turning the key in outside lever, <u>OR</u> Rotating the inside lever, <u>OR</u> Closing the door—all only when the slotted push button is unlocked, Turning back the slotted button. 	Cannot be locked Always unlocked
H F93		<ul style="list-style-type: none"> Rotating the inside lever, <u>OR</u> Turning the key in the outside lever—only when the inside push button is out, <u>OR</u> Removing the core with a control key and using a special emergency key. 	Always fixed	Key block feature is released by: <ul style="list-style-type: none"> Rotating the inside lever, <u>OR</u> Closing the door. 	Cannot be locked Always unlocked
HJ F93		<ul style="list-style-type: none"> Rotating the inside lever, <u>OR</u> Turning the key in the outside lever—only when the inside push button is out, <u>OR</u> Removing the core with a control key and using a special emergency key. 	Always fixed	Key block feature is released by: <ul style="list-style-type: none"> Rotating the inside lever, <u>OR</u> Closing the door. 	Cannot be locked Always unlocked
*Pushing the inside button displays an "occupied" indicator in the outside lever and blocks all operating keys.					
R F84		<ul style="list-style-type: none"> Rotating the inside lever, <u>OR</u> Turning the key in the outside lever, <u>OR</u> Rotating the outside lever when not locked by key. 	Turning the key in the outside lever.	Turning the key in the outside lever.	Cannot be locked Always unlocked
T F90		<ul style="list-style-type: none"> Rotating the inside lever, <u>OR</u> Rotating the outside lever when not locked by key or push button. 	<ul style="list-style-type: none"> Turning the key in the outside lever, <u>OR</u> Pushing the button on the inside lever. 	<ul style="list-style-type: none"> Turning the key in the outside lever, <u>OR</u> Rotating the inside lever (only when locked by push button), <u>OR</u> Closing the door (only when locked by push button). 	Cannot be locked Always unlocked

Double keyed functions*

C F88		<ul style="list-style-type: none"> Rotating the inside lever, <u>OR</u> Rotating the outside lever when not locked by key, <u>OR</u> Turning the key in the outside lever. 	Turning the key in the inside lever.	Turning the key in the inside lever.	Cannot be locked Always unlocked
----------	---	---	--------------------------------------	--------------------------------------	---------------------------------------

***WARNING:** Locksets that secure both sides of the door are controlled by building codes and the Life Safety Code. In an emergency exit situation, failure to quickly unlock the inside lever could be hazardous or even fatal.

9K VARSITY SERIES—FUNCTION DESCRIPTIONS

Function & Diag. (ANSI No.)	Diagram	Description			
		Latch operated by	Outside lever locked by	unlocked by	Inside lever locked by unlocked by
G F91		<ul style="list-style-type: none"> Rotating the outside lever when not locked by key, <u>OR</u> Rotating the inside lever when not locked by key. 	<ul style="list-style-type: none"> Turning the key in the inside lever, <u>OR</u> Turning the key in the outside lever. 	<ul style="list-style-type: none"> Turning the key in the inside lever, <u>OR</u> Turning the key in the outside lever. 	<ul style="list-style-type: none"> Turning the key in the inside lever, <u>OR</u> Turning the key in the outside lever.
*Turning the key in either the inside <u>OR</u> the outside, locks or unlocks both sides.					
S F80		<ul style="list-style-type: none"> Turning the key in the inside lever, <u>OR</u> Turning the key in the outside lever, <u>OR</u> Rotating the inside or outside lever (if unlocked). 	Turning the key in the outside lever.	Turning the key in the outside lever.	Turning the key in the inside lever. Turning the key in the inside lever.
*Turning the key in either lever, locks or unlocks its own lever independently.					
W F87		<ul style="list-style-type: none"> Turning the key in the inside lever, <u>OR</u> Turning the key in the outside lever. 	Always fixed	Cannot be unlocked	Always fixed Cannot be unlocked
Keyless functions					
L		<ul style="list-style-type: none"> Rotating the inside lever, <u>OR</u> Rotating the outside lever only when the inside push button is out. 	Pushing the inside button.	<ul style="list-style-type: none"> Rotating the outside slotted button, <u>OR</u> Rotating the inside lever, <u>OR</u> Closing the door. 	Cannot be locked Always unlocked
N F75		<ul style="list-style-type: none"> Rotating the inside lever, <u>OR</u> Rotating the outside lever. 	Cannot be locked	Always unlocked	Cannot be locked Always unlocked
NX F75		Rotating the inside lever.	Always fixed	Cannot be unlocked	Cannot be locked Always unlocked
P F77		<ul style="list-style-type: none"> Rotating the inside lever, <u>OR</u> Rotating the outside lever—only when the inside push button is out. 	Pushing the inside button.	<ul style="list-style-type: none"> Rotating the inside lever, <u>OR</u> Closing the door. 	Cannot be locked Always unlocked
Y		Rotating the inside lever.			Cannot be locked Always unlocked
1DT		This is a single, surface-mounted lever for an inactive door or a non-latching door.			
		This is a through-bolt mounted pair of matching levers for an inactive door or a non-latching door.			

9K VARSITY SERIES ORDER PROCEDURE

93K	7	AB	14	C	STK	626	LL	1 3/8"
1)Series	2)Core Housing	3)Function Code	4)Lever Style	5)Rose Style	6)Strike Style	7)Finish	8)Option	9) Door Thickness

1) Series	3) Function Code	6) Strike Style
-----------	------------------	-----------------

93K - 2 3/4" Backset
 94K - 3 3/4" Backset
 95K - 5" Backset

2) Core Housing

0 - Keyless
 7 - 7 Pin

3) Function Code

Standard Functions

AB - Corridor
 C - Apartment
 D - Storeroom
 E - Service Station
 G - Store
 H - Hotel
 HJ - Hotel (No Indicator)
 L - Privacy
 N - Passage
 NX - Exit Lock
 P - Patio
 R - Classroom
 S - Communicating
 T - Dormitory
 W - Institutional
 Y - Exit
 1DT - Dummy Trim
 2DT - Dummy Trim
 DEU - Electrically unlocked
 DEL - Electrically locked

Optional Functions

A - Entry
 B - Office
 DZ - Closet
 EA - Entry
 LL - Hospital Privacy
 M - Communicating
 Q - Exit
 RD - Special
 RZ - Closet
 DR - Special
 XR - Special
 XD - Special
 YD - Exit
 YR - Exit
 Z - Closet

7) Finish

605 - Bright Brass
 606 - Satin Brass
 611 - Bright Bronze
 612 - Satin Bronze
 613 - Oxidized Bronze
 625 - Bright Chrome
 626 - Satin Chrome

8) Option

AL - Abrasive Lever
 LL - Lead Lined
 SH - Security Head Screws
 TL - Tactile Lever
 3/4 - 3/4" Throw Latch

4) Lever Style

14 - Curved Return
 15 - Contour Angle Return
 16 - Curved No Return

5) Rose Style

C - 3" Convex
 D - 3 1/2" Convex
 K - 3" Convex, No Ring
 L - 3 1/2" Convex, No Ring


9) Door Thickness

1 3/8"
 1 3/4" - 2 1/4" (standard thickness)


9K BORED LEVER LOCKSET TRIM

LEVERS


STYLE 14



E-55022




E-55021




E-55020


STYLE 15



E-55169




E-55170




E-55168


STYLE 16



E-55025



E-55024



E-55023

NOTE: "H" Function Lever B-55100*


A-55177

B-55110*

ROSES *

STYLE C

(2) B-55512
Thru-bolt
Screws




(2) B-55015
Rose Trim

A-55603
Small O/S
Liner

C-55509
Small Inside
Liner

STYLE D

(2) B-55512
Thru-bolt
Screws




(2) B-55007
Rose Trim

B-55602
Large O/S
Liner

C-55508
Large Inside
Liner

STYLE K

(2) B-55512
Thru-bolt
Screws




(2) B-55018
Rose Trim

B-55603
Small O/S
Liner

C-55509
Small Inside
Liner

STYLE L

(2) B-55512
Thru-bolt
Screws




(2) B-55017
Rose Trim


A-55602
Large O/S
Liner

C-55508
Large Inside
Liner


STRIKES




DEADLOCKING LATCHES




SPRING LATCHES




RETRACTOR COMPONENTS



Catch Plate Spring




Retractor Spring




1-3/8" DOOR SPACERS

For 1-3/8" thick doors, include proper spacers

Small Rose Spacer





Large Rose Spacer




MISCELLANEOUS


Throw Members




Emergency Driver




Drill Jig



Spring loading Tool




Spanner Wrench



ITEM	PART NO.	DESCRIPTION	REQ'D
1	E-55024*	Button Lever Assembly	1
2	B-55018*	Rose Trim	2
3	C-55509*	Inside Rose Liner	1
4	A-55685	Inside Hub Assy.	1
5	B-55610	Non-Keyed Sleeve Assy.	1
6	A-55518	Lever Return Spring	2
7	B-55504	Thrust Plate	2
8	B-54172	Chassis Cover	1
9	B-54886	Retractor Assy.	1
10	A-25359	Latch Screw	2
11	C-54680*	Latch	1
12	B-55692	Turn Button Assy.	1
13	A-55673	Key Release Cam Assy.	1
14	B-55515	Spring Drive Plate	2
15	D-55501	Outside Hub	1
16	A-54200*	Throw Member	1
17	E-55023*	Keyed Lever	1
18	A-55603*	Outside Liner & Stud Assy.	1
19	A-55512	Thru-bolt Mounting Screws	2
20	A-55505	Chassis Screw	2
21	A-55687	Keyed Sleeve Assy.	1

* Indicates part number for item illustrated. See illustrations on pages 8 & 9 for additional part numbers.



93K7AB16K

FED. SPEC. 161A


ANSI F81-1 ENTRANCE LOCK

Deadlocking latchbolt retracted by either lever. Pushing button locks outside lever until unlocked by key outside, turning inside lever or closing door. Pushing and turning button locks outside lever. Latch is retracted by key or by turning inside lever. Outside lever remains locked until button is manually returned to unlocked position.

AB

ITEM	PART NO.	DESCRIPTION	REQ'D
1	E-55025*	Plain Lever Assembly	1
2	B-55018*	Rose Trim	2
3	C-55509*	Inside Rose Liner	1
4	A-55685	Inside Hub Assy.	1
5	B-55610	Non-Keyed Sleeve Assy.	1
6	A-55518	Lever Return Spring	2
7	B-55504	Thrust Plate	2
8	B-54172	Chassis Cover	1
9	B-54888	Retractor Assy.	1
10	A-25359	Latch Screw	2
11	C-54680*	Latch	1
12	A-55675	Key Release Cam Assy.	1
13	B-55515	Spring Drive Plate	1
14	D-55501	Outside Hub	1
15	A-54200*	Throw Member	1
16	E-55023*	Keyed Lever Assembly	1
17	A-55603*	Outside Liner & Stud Assy.	1
18	A-55512	Thru-bolt Mounting Screws	2
19	A-55505	Chassis Screw	2
20	A-55687	Keyed Sleeve Assy.	1

* Indicates part number for item illustrated. See illustrations on Pages 8 & 9 for additional part numbers.



BEST

93K7D16K

FED. SPEC. 161D

ANSI F86-1 STOREROOM OR CLOSET


LOCK

Deadlocking latchbolt retracted by either key in outside lever or by rotating inside lever. Outside lever is always fixed.

D

ITEM	PART	DESCRIPTION	REQ'D
1	E-55C	Button Lever Assembly	2
2	B-5501	Rose Trim	2
3	C-55509*	Inside Rose Liner	1
4	A-55685	Inside Hub Assy.	1
5	B-55610	Non-Keyed Sleeve Assy.	1
6	A-55518	Lever Return Spring	2
7	B-55504	Thrust Plate	2
8	B-54172	Chassis Cover	1
9	B-54886	Retractor Assy.	1
10	A-25359	Latch Screw	2
11	C-54681*	Spring Latch	1
12	A-55673	Key Release Cam Assy.	1
13	B-55515	Spring Drive Plate	1
14	B-54745	Button Release Assy.	1
15	D-55501	Outside Hub	1
16	A-55603*	Outside Liner & Stud Assy.	1
17	A-55512	Thru-bolt Mounting Screws	2
18	A-55505	Chassis Screw	2
19	B-55693	Push Button Bar Assy.	1
20	A-55687	Keyed Sleeve Assy.	1

* Indicates part number for item illustrated. See illustrations on pages 8 & 9 for additional part numbers.



BEST

93KOL16K

FED. SPEC. 161L

ANSI F76-1 PRIVACY, BEDROOM OR BATH LOCK

Spring latchbolt operated by lever from either side. Outside lever is locked by push-button inside and unlocked by emergency driver in slotted button outside rotating inside lever or closing door.


BEST LOCK CORPORATION

INDIANAPOLIS, INDIANA

Printed in U.S.A.

ITEM	PART NO.	DESCRIPTION	REQ'D
1	E-55025*	Plain Lever Assembly	2
2	B-55018*	Rose Trim	2
3	C-55509*	Inside Rose Liner	1
4	A-55685	Inside Hub Assy.	1
5	B-55610	Non-Keyed Sleeve Assy.	2
6	A-55518	Lever Return Spring	2
7	B-55504	Thrust Plate	2
8	B-54172	Chassis Cover	1
9	B-54888	Retractor Assy.	1
10	A-25359	Latch Screw	2
11	C-54681*	Spring Latch	1
12	D-55501	Outside Hub	1
13	A-55603*	Outside Liner & Stud Assy.	1
14	A-55512	Thru-bolt Mounting Screws	2
15	A-55505	Chassis Screw	2

* Indicates part number for item illustrated. See illustrations on pages 8 & 9 for additional part numbers.



BEST

93KON16K


FED. SPEC. 161N

ANSI F75-1 PRIVACY OR CLOSET LOCK

Spring latchbolt operated by lever from either side at all times.

ITEM	PART NO.	DESCRIPTION	REQ'D
1	B-550	Plain Lever Assembly	1
2	B-550	Rose Trim	2
3	C-55509	Inside Rose Liner	1
4	A-55685	Inside Hub Assy.	1
5	B-55610	Non-Keyed Sleeve Assy.	1
6	A-55518	Lever Return Spring	2
7	B-55504	Thrust Plate	2
8	B-54172	Chassis Cover	1
9	B-54888	Retractor Assy.	1
10	A-25359	Latch Screw	2
11	C-54680*	Latch	1
12	A-55681	Key Release Cam Assy.	1
13	B-55515	Spring Drive Plate	1
14	E-55687	Keyed Sleeve Assy.	1
15	D-55501	Outside Hub	1
16	A-54200*	Throw Member	1
17	E-55023*	Keyed Lever Assembly	1
18	A-55603*	Outside Liner & Stud Assy.	1
19	A-55512	Thru-bolt Mounting Screws	2
20	A-55505	Chassis Screw	2

* Indicates part number for item illustrated. See illustrations on pages 8 & 9 for additional part numbers.



BEST

93K7R16K

FED. SPEC. 161R

ANSI F84-1 CLASSROOM LOCK

Deadlocking latchbolt operated by lever either side except when outside lever is locked by key. Latchbolt is operated by key outside or by rotating inside lever.

R