

Filter Sections:

1. Check filters and replace if dirty.
2. Check filter access door gaskets and filter seals. Replace if required.
3. Check filter manometer and calibrate if required.

Caution: Do not use metal ladders.

Caution: When using a stepladder, never stand on the top step of the ladder.

Caution: When opening duct access door at the filters remember that the duct may be under a positive pressure. Either turn off the respective AHU or carefully open the door keeping in mind to maintain pressure on the face of the door to prevent it from flying open upon release of the door latch.