

E. Lubrication Data

Outside stem and yoke (OS&Y) valve(s) should be operated (closed and opened) annually (see tables 5.1 and 12.1, Section F of this manual). If operation of the valve(s) is not smooth, grease should be applied to the brass stem, and the valve packing adjusted.