

Fire Dampers and Smoke Dampers:

1. Check fire damper and fire/smoke damper and fusible link.
2. Check smoke damper opening and closing in sequence with the starting and stopping of air handling unit operation.

Caution: Do not use metal ladders.

Caution: When using a stepladder, never stand on the top step of the ladder.

Caution: Fire/smoke dampers are located above ceilings. Wear safety glasses when servicing this equipment to prevent falling debris from injuring the eyes or from air blown particles when opening duct access door.

Caution: When opening duct access door at the fire/smoke damper remember that the duct may be under a positive pressure. Either turn off the respective AHU or carefully open the door keeping in mind to maintain pressure on the face of the door to prevent it from flying open upon release of the door latch.