

\*\*\*\*\*  
USACE / NAVFAC / AFCEA UFGS-11601 (August 2004)  
-----  
Preparing Activity: NAVFAC Superseding  
UFGS-11601N (August 2001)

## UNIFIED FACILITIES GUIDE SPECIFICATIONS

References are in agreement with UMRL dated 23 June 2005

Latest change indicated by CHG tags

\*\*\*\*\*

### SECTION TABLE OF CONTENTS

#### DIVISION 11 - EQUIPMENT

##### SECTION 11601

#### LABORATORY EQUIPMENT AND FUMEHOODS

08/04

#### PART 1 GENERAL

- 1.1 REFERENCES
- 1.2 RELATED WORK SPECIFIED IN OTHER SECTIONS
- 1.3 SUBMITTALS
- 1.4 SUBMITTAL REQUIREMENTS
  - 1.4.1 Hood Paint
  - 1.4.2 Drawing Requirements
  - 1.4.3 Schedule
  - 1.4.4 Tests

#### PART 2 PRODUCTS

- 2.1 MATERIALS, COMPONENTS, AND SPECIAL DESIGN REQUIREMENTS
  - 2.1.1 Aluminum Alloy
  - 2.1.2 Carbon Steel
  - 2.1.3 Stainless Steel
  - 2.1.4 Safety Glass
  - 2.1.5 Casework Components
  - 2.1.6 High Efficiency Particulate Air (HEPA) Filter
  - 2.1.7 Fumehood Design
  - 2.1.8 Hood Static Pressure Loss
  - 2.1.9 Electrical Devices
- 2.2 UNITS
  - 2.2.1 Unit [\_\_\_\_\_, \_\_\_\_\_]
    - 2.2.1.1 Base Cabinet Portion of Assembly
    - 2.2.1.2 Hood Interior
    - 2.2.1.3 Sash
  - 2.2.2 Fumehood Assembly, Constant Volume
    - 2.2.2.1 Base Cabinet Portion of Assembly
    - 2.2.2.2 Hood Interior, Including Working Surface
    - 2.2.2.3 Sash
    - 2.2.2.4 Baffle
    - 2.2.2.5 Lighting Fixtures

- 2.2.2.6 Service Fixtures
- 2.2.2.7 Blower Switch
- 2.2.2.8 Duct Stub
- 2.2.3 Radio Isotope Fumehood With Vent
  - 2.2.3.1 Base Cabinet Portion of Assembly
  - 2.2.3.2 Hood Interior, Including Working Surface
  - 2.2.3.3 Sash
  - 2.2.3.4 Lead Lining
  - 2.2.3.5 Baffle
  - 2.2.3.6 Lighting Fixture
  - 2.2.3.7 Mirror
  - 2.2.3.8 Service Fixtures
  - 2.2.3.9 Blower Switch
  - 2.2.3.10 Duct Stub
  - 2.2.3.11 Replaceable Filter
  - 2.2.3.12 Warning System
- 2.2.4 Biological Safety Cabinet
  - 2.2.4.1 Glove Panel
  - 2.2.4.2 Light Fixture[s]
  - 2.2.4.3 Service Fittings
  - 2.2.4.4 Viewing Panel
  - 2.2.4.5 Blower Switch
  - 2.2.4.6 Duct Stub
  - 2.2.4.7 Intake and Exhaust Filters
  - 2.2.4.8 Warning System

### PART 3 EXECUTION

- 3.1 INSTALLATION
- 3.2 POSTED OPERATING INSTRUCTIONS
- 3.3 FIELD QUALITY CONTROL
  - 3.3.1 Inspection
  - 3.3.2 Tests

-- End of Section Table of Contents --

\*\*\*\*\*  
USACE / NAVFAC / AFCEA UFGS-11601 (August 2004)  
-----  
Preparing Activity: NAVFAC Superseding  
UFGS-11601N (August 2001)

## UNIFIED FACILITIES GUIDE SPECIFICATIONS

References are in agreement with UMRL dated 23 June 2005

Latest change indicated by CHG tags

\*\*\*\*\*

### SECTION 11601

#### LABORATORY EQUIPMENT AND FUMEHOODS 08/04

\*\*\*\*\*

NOTE: This guide specification covers the requirements for laboratory equipment and fume hoods.

Comments and suggestions on this guide specification are welcome and should be directed to the technical proponent of the specification. A listing of technical proponents, including their organization designation and telephone number, is on the Internet.

Recommended changes to a UFGS should be submitted as a Criteria Change Request (CCR).

Use of electronic communication is encouraged.

Brackets are used in the text to indicate designer choices or locations where text must be supplied by the designer.

\*\*\*\*\*

\*\*\*\*\*

NOTE: Types of equipment normally specified in this section include fumehoods, furniture not specified in casework section, and related laboratory products. Laboratory fumehoods included by the guide specification are not to be utilized for perchloric acid handling operations. Perchloric acid is extremely dangerous because it is a very strong oxidizer. When this acid reacts with organic material, an explosive product may form.

\*\*\*\*\*

\*\*\*\*\*

NOTE: On the drawings, show:

1. Location of equipment, utility connections and relation to other work.
2. Remotely located blower and ductwork, to create negative pressure at hood. Require weatherproof

caution labels attached to outlet end of exhaust systems where warning of dangerous chemical fumes will be necessary.

3. Fans and ductwork needed to create negative pressure. Laboratory fume hoods are ventilated enclosures designed to provide safe working area for laboratory activities involving hazardous materials, generated fumes, aerosols, gases, and particulate matter. To operate satisfactorily, air is removed from enclosure at optimum face velocity. Require velocities measurable at maximum face area of hood, with maximum allowances for hood, filter, and appurtenance static pressure losses within specified limits.

\*\*\*\*\*

## PART 1 GENERAL

### 1.1 REFERENCES

\*\*\*\*\*

NOTE: Issue (date) of references included in project specifications need not be more current than provided by the latest guide specification. Use of SpecsIntact automated reference checking is recommended for projects based on older guide specifications.

\*\*\*\*\*

The publications listed below form a part of this specification to the extent referenced. The publications are referred to within the text by the basic designation only.

#### AMERICAN CONFERENCE OF GOVERNMENTAL INDUSTRIAL HYGIENISTS (ACGIH)

ACGIH-2092S (1998) Industrial Ventilation: A Manual of Recommended Practice

#### ASTM INTERNATIONAL (ASTM)

ASTM A 167 (2004) Stainless and Heat-Resisting Chromium-Nickel Steel Plate, Sheet, and Strip

ASTM A 366/A 366M (1997e1) Commercial Steel, Sheet, Carbon, (0.15 Maximum Percent Cold-Rolled

ASTM B 221 (2004a) Aluminum and Aluminum-Alloy Extruded Bars, Rods, Wire, Profiles, and Tubes

ASTM B 221M (2004) Aluminum and Aluminum-Alloy Extruded Bars, Rods, Wire, Profiles, and Tubes (Metric)

ASTM C 1048 (2004) Heat-Treated Flat Glass - Kind HS, Kind FT Coated and Uncoated Glass

CENTERS FOR DISEASE CONTROL AND PREVENTION (CDC)

CDC BMBL (1999) Biosafety in Microbiological and Biomedical Laboratories, 4th Edition

NATIONAL FIRE PROTECTION ASSOCIATION (NFPA)

NFPA 45 (2000) Fire Protection for Laboratories Using Chemicals

NFPA 70 (2005) National Electrical Code

UNDERWRITERS LABORATORIES (UL)

UL 586 (1996; Rev thru Apr 2000) High-Efficiency, Particulate, Air Filter Units

1.2 RELATED WORK SPECIFIED IN OTHER SECTIONS

Conform to provisions of Section 11700 GENERAL REQUIREMENTS FOR MEDICAL AND DENTAL EQUIPMENT and Section 12350 CASEWORK FOR MEDICAL AND DENTAL FACILITIES. Provide final utility connections and utility service to equipment including waste, under Sections 15050N BASIC MECHANICAL MATERIALS AND METHODS; 15400 PLUMBING SYSTEMS; 15217N MEDICAL GAS AND VACUUM PIPING; 16050N BASIC ELECTRICAL MATERIALS AND METHODS; and 16402 INTERIOR DISTRIBUTION SYSTEM.

1.3 SUBMITTALS

\*\*\*\*\*

NOTE: Submittals must be limited to those necessary for adequate quality control. The importance of an item in the project should be one of the primary factors in determining if a submittal for the item should be required.

A "G" following a submittal item indicates that the submittal requires Government approval. Some submittals are already marked with a "G". Only delete an existing "G" if the submittal item is not complex and can be reviewed through the Contractor's Quality Control system. Only add a "G" if the submittal is sufficiently important or complex in context of the project.

For submittals requiring Government approval on Army projects, a code of up to three characters within the submittal tags may be used following the "G" designation to indicate the approving authority. Codes for Army projects using the Resident Management System (RMS) are: "AE" for Architect-Engineer; "DO" for District Office (Engineering Division or other organization in the District Office); "AO" for Area Office; "RO" for Resident Office; and "PO" for Project Office. Codes following the "G" typically are not used for Navy projects.

Submittal items not designated with a "G" are

considered as being for information only for Army  
projects and for Contractor Quality Control approval  
for Navy projects.

\*\*\*\*\*

Government approval is required for submittals with a "G" designation; submittals not having a "G" designation are [for Contractor Quality Control approval.] [for information only. When used, a designation following the "G" designation identifies the office that will review the submittal for the Government.] The following shall be submitted in accordance with Section 01330 SUBMITTAL PROCEDURES:

SD-02 Shop Drawings

Laboratory equipment and fume hood layout; G, [\_\_\_\_\_]

Laboratory equipment and hood schedules

SD-03 Product Data

Fumehood assembly; G, [\_\_\_\_\_]

Radio isotope fumehood; G, [\_\_\_\_\_]

Biological safety cabinet; G, [\_\_\_\_\_]

Include descriptive literature, technical data sheets, and diagrams.

SD-04 Samples

Exterior hood paint; G, [\_\_\_\_\_]

SD-06 Test Reports

Fumehood test; G, [\_\_\_\_\_]

Base cabinet test; G, [\_\_\_\_\_]

SD-08 Manufacturer's Instructions

Fumehood assembly

Radio isotope fumehood

Biological safety cabinet

SD-10 Operation and Maintenance Data

Fumehood assembly, Data Package 2; G, [\_\_\_\_\_]

Radio isotope fumehood, Data Package 2; G, [\_\_\_\_\_]

Biological safety cabinet, Data Package 2; G, [\_\_\_\_\_]

Submit in accordance with Section 01781 OPERATION AND MAINTENANCE DATA.

#### 1.4 SUBMITTAL REQUIREMENTS

##### 1.4.1 Hood Paint

Submit color chips of exterior hood paint. Submit [at least five] colors which are standard with the manufacturer.

##### 1.4.2 Drawing Requirements

Show pertinent installation layout. Indicate details of construction and rough-in requirements.

##### 1.4.3 Schedule

Include each type of equipment and hood and submit in accordance with Section 11700 GENERAL REQUIREMENTS FOR MEDICAL AND DENTAL EQUIPMENT.

##### 1.4.4 Tests

Submit fumehood test [and] cabinet test reports required by ACGIH-2092S.

#### PART 2 PRODUCTS

##### 2.1 MATERIALS, COMPONENTS, AND SPECIAL DESIGN REQUIREMENTS

\*\*\*\*\*  
NOTE: Use of certain chemicals such as hydrochloric and hydrofluoric acids may react with specified materials. Epoxy, mineral, or synthetic materials for hood interior working area, acid wastes, and drains may be required depending on chemicals to be used. If other materials are required, add text.  
\*\*\*\*\*

##### 2.1.1 Aluminum Alloy

ASTM B 221MASTM B 221 equivalent in ultimate tensile, yield, and shear strengths to Alloy 6063-T5 or 6063-T6.

##### 2.1.2 Carbon Steel

ASTM A 366/A 366M, cold rolled sheets, commercial bright finish.

##### 2.1.3 Stainless Steel

ASTM A 167; No 4 satin finish including welds and fabricated surfaces. Provide Type 302, 304, or 316 alloy unless otherwise specified. Provide minimum thickness of 1.5 mm U.S. Standard 16 gage, except 1.8 mm thick 14 gage for working surface.

##### 2.1.4 Safety Glass

ASTM C 1048, fully tempered "FT," clear.

##### 2.1.5 Casework Components

Conform with Section 12350 CASEWORK FOR MEDICAL AND DENTAL FACILITIES for base cabinets, counter tops, service fittings and finishes.

#### 2.1.6 High Efficiency Particulate Air (HEPA) Filter

Meet requirements of UL 586.

#### 2.1.7 Fumehood Design

Design, calculate face velocities, and test fume hoods in accordance with ACGIH-2092S, Laboratory fume hoods, auxiliary systems, and associated equipment shall meet the requirements of NFPA 70 and NFPA 45.

#### 2.1.8 Hood Static Pressure Loss

\*\*\*\*\*

**NOTE: For determining the system total static pressure loss for sizing blowers, use the hood maximum static pressure loss when operating at 46 mpm 150 fpm face velocity; allow 50 mm 2 inch water gage loss for dirty HEPA filter and 25 mm one inch water gage additional loss for a downstream charcoal filter or a prefilter (or the filter manufacturer's recommended resistance at the rated cfm of exhaust air).**

\*\*\*\*\*

With the sash in full-open position the static pressure loss through the fumehood shall not exceed 13 mm 1/2 inch water gage when operating at 23 mpm 75 feet per minute (fpm), 22 mm 7/8 inch water gage at 30 mpm 100 fpm, 29 mm 1.125 inch water gage at 38 mpm 125 fpm. For hoods equipped with bypass, the static pressure loss and exhaust volume shall remain relatively constant (within 5 percent) regardless of sash position.

#### 2.1.9 Electrical Devices

Prewired at the factory to a common, integral junction box to provide easy exterior connection and disconnection.

### 2.2 UNITS

#### 2.2.1 Unit [\_\_\_\_, \_\_\_\_]

##### 2.2.1.1 Base Cabinet Portion of Assembly

[\_\_\_\_].

##### 2.2.1.2 Hood Interior

[\_\_\_\_].

##### 2.2.1.3 Sash

[\_\_\_\_].

#### 2.2.2 Fumehood Assembly, Constant Volume

\*\*\*\*\*

**NOTE: Provide packaged heater assembly for tempering cold outside air when auxiliary air type hoods are specified.**

\*\*\*\*\*



Constant volume, [auxiliary air] [bypass/airfoil] configuration, enclosed unit mounted on base cabinet; exterior dimensions maximum 1245 mm wide (across face) by 750 mm deep (front to back) by 2400 mm high 49 inches wide (across face) by 30 inches deep (front to back) by 96 inches high; interior working area at least 900 mm wide by 600 mm deep by 1195 mm high 36 inches wide 24 inches deep by 47 inches high.

#### 2.2.2.1 Base Cabinet Portion of Assembly

Carbon steel, modified to have recessed apron to contain electrical convenience outlets.

#### 2.2.2.2 Hood Interior, Including Working Surface

Type 304 stainless steel, with interior vertical joints and intersections of vertical surface with working surface having an approximate 20 mm 3/4 inch radius. Provide working surface with a raised rim around all sides to prevent spillage from running out face of hood.

#### 2.2.2.3 Sash

Safety glass, 5.6 mm 7/32 inch minimum thickness, counterbalanced, vertical sliding type, Type 304 stainless steel frame.

#### 2.2.2.4 Baffle

Adjustable, with moving parts resistant to corrosion, removable for cleaning.

#### 2.2.2.5 Lighting Fixtures

[Explosion proof] [Vapor proof], fluorescent, with cool white lamps and switch, providing 800 lux 75 foot candles on working area. Locate switch for fixture on exterior of hood frame, or in recess of base cabinet. Provide sealed safety glass window barrier between interior working and fixture spaces, and access for tube replacement exterior to hood interior working area.

#### 2.2.2.6 Service Fixtures

Provide remote controls for piped services and locate on hood exterior frame. Provide serrated supply ends with nozzles arranged close to sash, precluding the need of reaching to interior back of hood to make connections to outlets. Base metal of fixtures shall be brass. Protect metal fixtures inside hood with chemical resistant coating of [clear plastic over polished chrome plate] [or] [\_\_\_\_\_].

- a. Cold water: Remote controlled valve, with vacuum breaker; hood wall mounted gooseneck faucet with serrated nozzle. Arrange faucet parallel to hood wall and over cup sink.
- b. Gas, air and vacuum: Provide fixtures for each service, each fitting with remote controlled valve and supply end (inside hood) consisting of a serrated hose nozzle and escutcheon trim. Provide natural gas, air at 685 kPa 85 psig, and vacuum at 750 mm 30 inches of HG.
- c. Acid waste: Recessed cup sink, 75 by 150 mm 3 by 6 inches or 75

by 225 mm 3 by 9 inches, fabricated of Type 316 stainless steel, 2 liter capacity. Furnish with acid waste p-trap and locate under water faucet, integral with countertop. Provide acid vent.

- d. Electrical convenience outlets: Two duplex, grounded, three-wire, 125 volt, 60 Hz, single phase [and one 240 volt single phase], 20 ampere. Locate in recessed area of base cabinet or on side posts of hood. Provide stainless steel or chrome-plated cover plate. [Provide 15 ampere circuit breaker protection.]

#### 2.2.2.7 Blower Switch

\*\*\*\*\*  
NOTE: Coordinate switch requirements with specifications for the blowers for fume hoods. Fans requiring switches not discussed in the paragraph cited above (e.g., greater than one horsepower or 208-volt) shall have a single pole switch with an indicator light.  
\*\*\*\*\*

[Single-pole, 115-volt] [Double-pole, 208-volt], 60-Hz, with pilot light. Locate switch in hood frame or in recess of base cabinet.

#### 2.2.2.8 Duct Stub

\*\*\*\*\*  
NOTE: Verify that ductwork to hoods is discussed in the appropriate documents and that blowers for the hoods are located at exhaust end. Avoid positive pressure in ducts.  
\*\*\*\*\*

Collar size suitable for ductwork indicated. Finish of areas that may come in direct contact with fumes shall be same material and finish as hood interior.

#### 2.2.3 Radio Isotope Fumehood With Vent

Enclosed, isotope-type hood mounted on base cabinet of [auxiliary air] [bypass/airfoil] configuration. Maximum exterior dimensions: 900 mm wide (across face) by 750 mm ddep (front to back) by 2400 mm high (including base) 36 inches wide (across face) by 30 inches deep (front to back) by 96 inches high (including base). Minimum interior working area: 750 by 600 mm deep by 1170 mm high 30 by 24 inches deep by 46 inches high.

##### 2.2.3.1 Base Cabinet Portion of Assembly

Carbon steel comparable to a sink cupboard section, modified to have recessed apron to contain electrical convenience outlets.

##### 2.2.3.2 Hood Interior, Including Working Surface

Type 304 stainless steel, with interior vertical joints and intersections of vertical surface with working surface having an approximate 20 mm 3/4 inch radius. Working surface shall have a raised rim all around to prevent spillage from running out face of hood.

#### 2.2.3.3 Sash

\*\*\*\*\*  
NOTE: Several materials are available for sash.  
Clear safety glass is acceptable where minimum  
storage of materials allows use of lead bricks as a  
front barrier. Lead safety glass provides  
excellent protection but scratches easily.  
Bulletproof glass and various plastics have good  
resistance to certain levels of radiation.  
\*\*\*\*\*

[Safety glass] [Lead (equivalent to [\_\_\_\_\_] mm inch lead protection)  
safety glass] [\_\_\_\_\_] , vertical sliding type, counterbalanced.

#### 2.2.3.4 Lead Lining

Concealed, [\_\_\_\_\_] mm inch[es] thick. Provide with lapped seams,  
protecting areas adjacent to the three enclosed vertical sides of the hood  
[and the area below working surface of hood]. Lap sash area and  
intersections with adjacent surfaces at least 10 mm 3/8 inch.

#### 2.2.3.5 Baffle

Adjustable with moving parts resistant to corrosion, removable for cleaning.

#### 2.2.3.6 Lighting Fixture

Vapor proof, fluorescent, with cool white lamps and switch, providing 800  
lux 75 foot candles on working area. Locate switch for fixture on exterior  
front of hood, or in recess of base cabinet.

#### 2.2.3.7 Mirror

\*\*\*\*\*  
NOTE: Mirror is for view behind lead brick barrier.  
Clear safety glass is acceptable where minimum  
storage of materials allows use of lead bricks as a  
front barrier. Lead safety glass provides  
excellent protection but scratches easily.  
Bulletproof glass and various plastics have good  
resistance to certain levels of radiation. It may  
be desirable for any sash finish. Delete if special  
equipment must be attached to back interior.  
\*\*\*\*\*

Fully framed, fully adjustable, and suitably backed to prevent fume damage  
to silvering.

#### 2.2.3.8 Service Fixtures

Locate remote controls for piped services on hood exterior and provide  
serrated supply ends with nozzles arranged close to sash, precluding the  
need of reaching to interior back of hood to make connections to outlets.  
Base metal of fixtures shall be brass. Protect metal fittings inside hood  
with chemical resistant coating of [clear plastic over polished chrome  
plate] [or] [\_\_\_\_\_].

- a. Cold water: Remote controlled valve with vacuum breaker; hood

wall mounted gooseneck faucet with serrated nozzle. Arrange faucet parallel to hood wall.

- b. Natural gas and vacuum: Provide fixtures for each service, each fitting with remote controlled valve. Supply end (inside hood) consisting of a serrated hose nozzle and escutcheon trim. Provide natural gas and vacuum 750 mm HG 30 inches HG.
- c. Acid waste: Recessed cup sink, 750 by 150 or 75 by 225 mm 3 by 6 or 3 by 9 inches, fabricated of Type 316 stainless steel, 2 liter capacity. Furnish with acid waste p-trap and locate under water faucet, integral with countertop. Provide acid vent.
- d. Electrical convenience outlet: Two polarized duplex, grounded, three-wire, 125 volt, 60 Hz, single phase [and one 240 volt single phase], 20 ampere. Locate in recessed area of base cabinet or on side posts of hood. Provide stainless steel or chrome-plated cover plate. [Provide 15 ampere circuit breaker protection.]

#### 2.2.3.9 Blower Switch

\*\*\*\*\*  
NOTE: Coordinate switch requirements with specifications for the blowers for fume hoods. Fans requiring switches not discussed in the paragraphs cited above (e.g., greater than one horsepower or 208-volt) shall have a single pole switch with an indicator light.  
\*\*\*\*\*

[Single-pole, 115-volt] [Double-pole, 208-volt], 60-Hz, with pilot light. Locate switch in hood frame or in recess of base cabinet.

#### 2.2.3.10 Duct Stub

\*\*\*\*\*  
NOTE: Verify that ductwork to hoods is discussed in the appropriate documents and that blowers for the hoods are located at exhaust end. Avoid positive pressure in ducts.  
\*\*\*\*\*

Collar size suitable for ductwork indicated. Material of collar same as hood interior or metal coated with epoxy having corrosion resistance comparable to finish on fittings in hood.

#### 2.2.3.11 Replaceable Filter

[HEPA, efficiency [\_\_\_\_\_] percent] [and] [prefilter] [activated charcoal filter]; with stainless steel filter housing. HEPA filter static pressure loss shall not exceed 249 pascals one inch water gage when clean and operated at the rated airflow capacity.

#### 2.2.3.12 Warning System

Ensure detection and alarm for insufficient air velocities caused by failure of supply or exhaust system or by dirty filter. [Provide static pressure sensing switch in exhaust duct to shut off auxiliary air blower when failure occurs].

#### 2.2.4 Biological Safety Cabinet

Suitable for biological work and protecting the user from airborne infectious agents and similar hazardous particulate matter by providing an inward flow of air while preventing hazardous discharge into ambient atmosphere. Hood must meet the requirements for CDC BMBL, and have overall approximate dimensions of 1800 mm wide (across front) by 790 mm deep (front to back) by 2160 mm high 72 inches wide (across front) by 31 inches deep (front to back) by 85 inches high.

##### 2.2.4.1 Glove Panel

Removable, with two pairs of combination gloves, hand sections of surgical rubber, detachable from neoprene sleeves. Provide with built-in tubes connectable to air supply and appropriate "O" rings and clamps. Glove assembly removable, providing access into hood for bare-hand work. Hood shall meet the requirements for general purpose fume hoods of ACGIH-2092S, when operated with glove panel removed.

##### 2.2.4.2 Light Fixture[s]

Fluorescent, prewired, with cool white bulbs, with switch hood-mounted exterior to working area. [Ultraviolet, germicidal, prewired, single tube, with separate switch hood-mounted exterior to working area].

##### 2.2.4.3 Service Fittings

Locate remote controls for piped services on hood exterior; provide serrated supply end. Base metal of fixtures shall be brass. Protect metal fixtures inside hood with [chemical resistant coating of clear plastic over polished chrome plate] [or] [\_\_\_\_\_].

- a. Natural gas, air at 685 kPa 85 psig minimum, and vacuum at 750 mm 30 inches HG.
- b. Cold water: Remote controlled valve with vacuum breaker; hood-wall mounted gooseneck faucet with serrated nozzle. Arrange faucet parallel to hood wall.
- c. Sink and drain: 300 mm long by 150 mm wide by 50 mm deep 12 inches long by 6 inches wide by 2 inches deep; minimum of 1.25 mm 0.050 inch thick stainless steel, welded into surface of cabinet, corners coved to not less than 6 mm 1/4 inch radius. Provide with stainless steel strainer; drain plug; and 38 mm 1 1/2 inch borosilicate glass non-siphon P-Trap, with compression joints and bottom clean-out fitting.
- d. Electrical convenience outlets: Two polarized duplex, grounded, three-wire, 125 volt, 60-Hz., single phase [and one 240 volt single phase], 20 ampere. Locate on exterior of hood front or on hood side walls near hood front. Include stainless steel or chrome-plated cover plate. [Provide 15 ampere circuit breaker.]

##### 2.2.4.4 Viewing Panel

Safety glass, 5.56 mm 7/32 inch minimum thickness.

#### 2.2.4.5 Blower Switch

\*\*\*\*\*  
NOTE: Coordinate switch requirements with specifications for the blowers for fume hoods. Fans requiring switches not discussed in the paragraphs cited above (e.g., greater than 750 watt one horsepower or 208 volt) shall have a single pole switch with an indicator light.  
\*\*\*\*\*

[Single-pole, 115 volt] [Double-pole, 208 volt], 60 Hz, with pilot light. Include galvanized switch box and chrome-plated metal switch cover plate. Locate switch on hood exterior.

#### 2.2.4.6 Duct Stub

\*\*\*\*\*  
NOTE: Verify that ductwork to hoods is discussed in the appropriate documents and that blowers for the hoods are located at exhaust end. Avoid positive pressure in ducts.  
\*\*\*\*\*

Collar size suitable for ductwork indicated. Finish of areas that may come in direct contact with fumes to be same as to hood interior.

#### 2.2.4.7 Intake and Exhaust Filters

Replaceable HEPA filters having a minimum efficiency rating of 99.97 percent, including stainless steel housing. HEPA filter static pressure loss shall not exceed one inch water gage when clean and operated at the rated airflow capacity.

#### 2.2.4.8 Warning System

Ensure detection and alarm for insufficient air velocities caused by failure of exhaust system or by dirty filters.

### PART 3 EXECUTION

#### 3.1 INSTALLATION

Install units at locations indicated. Conform to installation provisions of Section 11700 GENERAL REQUIREMENTS FOR MEDICAL AND DENTAL EQUIPMENT [and utility installation provisions of] [Section 15195N NATURAL GAS AND LIQUID PETROLEUM PIPING;] [Section 15400 PLUMBING SYSTEMS;] [Section 15217N MEDICAL GAS AND VACUUM PIPING] [and] the ACGIH-2092S including provision for an adequate supply of tempered make-up air to meet the air flow requirements of fume hood(s). Provide interlocks for controls and alarms to maintain the required air balance between hood interiors and the room.

#### 3.2 POSTED OPERATING INSTRUCTIONS

Provide in accordance with the requirements in Section 15050N BASIC MECHANICAL METIRALS AND METHODS.

### 3.3 FIELD QUALITY CONTROL

#### 3.3.1 Inspection

Examine each unit for visual defects, operation and conformance to specifications.

#### 3.3.2 Tests

Test each unit to ensure that the equipment is operational and conforms to specification requirements. Field tests for fume hood operation and performance shall meet the requirements of ACGIH-2092S.

-- End of Section --