



CUT BACK SCREW SPLINE TO PROVIDE CONTINUOUS PLANE FOR MEMBRANE ADHESION. SEE FIGURE 7

SEALANT AT BUTT JOINTS BETWEEN HORIZONTAL & VERTICAL MULLIONS

NEOPRENE CORNER PLUGS SEALED WITH SILICONE SEALANT. ENSURE THAT SEALANT DOES NOT BLOCK DRAINAGE OR RETAIN WATER AT CORNERS. SEE FIGURE 6 (?)

MINIMUM 3/4" x 1/2" WEEP HOLES IN BOTTOM OF SNAP COVER. MINIMUM 3 PER LITE. DO NOT ALIGN WITH OPENINGS IN PRESSURE PLATE EXPANSION JOINT IN VERTICAL PRESSURE PLATE/BAR. SEAL JOINT. DO NOT LET SEALANT INTERFERE WITH SNAP COVER. OVERLAP PRESSURE PLATE/BAR FACE CREATING BAND-AID SEAL

EXPANSION JOINT IN SNAP COVER, 1/2" BELOW PRESSURE PLATE/BAR EXPANSION JOINT
SPICE SLEEVE

SEAL HORIZONTAL PRESSURE PLATE/BAR TO VERTICAL

NOTE: GLAZING GASKETS NOT SHOWN

NOTE: SEAL ALL SCREW HEADS AND BUTT JOINTS WITH SILICONE SEALANT AND SEAL AROUND SHEAR BLOCK DURING FRAME ASSEMBLY

PRESSURE PLATE/BAR

SNAP COVER

NOTE: SNAP COVERS CAN TYPICALLY BE CUSTOM EXTRUDED TO PROVIDE FOR VARYING ARCHITECTURAL EFFECT WITHOUT AFFECTING PERFORMANCE

NOTE: FOLLOW MANUFACTURER'S INSTRUCTIONS.

NOTE: CUT BACK BOTTOM OF SCREW SPLINE SIMILAR TO TOP. SEE FIGURE 7

FIGURE 5-6
ISOMETRIC OF FINISHED SYSTEM
STICK-BUILT SYSTEM (PE'D)
OUTSIDE GLAZED