



WEEP HOLES IN SNAP COVERS

SETTING BLOCKS AT 1/4 POINTS OR AS RECOMMENDED FOR SIZE OF GLAZING. MUST NOT BLOCK DRAINAGE

DRAINAGE SLOTS ALIGNED SO THAT THE BOTTOM IS FLUSH WITH OR JUST BELOW THE SCREW SPLINE TO ENSURE DRAINAGE
 DRAINAGE SLOTS MINIMUM 3/8" HIGH BY 1" LONG TO PROVIDE CAPILLARY BREAK
 MINIMUM THREE PER HORIZONTAL LITE, NONE IN VERTICAL PRESSURE PLATES/BARS

NOTE: WEEP HOLES IN SNAP COVERS SHALL BE OFFSET FROM DRAINAGE SLOTS

STAINLESS STEEL BOLTS SPACING DEPENDS ON LOAD

SCREW SPLINE BEHIND PRESSURE PLATE / BAR (DASHED)

FIGURE S-9
ELEVATION OF HORIZONTAL PRESSURE PLATE - CURTAIN WALL
STICK-BUILT SYSTEM (PE'D)
OUTSIDE GLAZED